

3716 0248 82

No	Part number	Description
1	3716 0429 80	Hydraulic motor
2	0211 1363 00	Cap screw
3	3715 3211 00	Gasket
4	3716 0379 00	Housing
5	3716 0249 00	Pinion
6	3716 0014 00	Washer
7	3716 0015 00	Lock plate
8	0147 1323 03	Screw
9	0504 2502 00	Ball bearing
10	0335 2141 00	Circlip
11	0663 2122 00	O-ring
12	3716 0251 00	Shaft
13	0211 1325 00	Cap screw
14	3716 0250 00	Gear wheel
15	0666 6000 11	Seal
16	0211 1321 00	Cap screw
17	3716 0164 00	Cap
18	3716 0008 00	Top nut
19	0335 2165 00	Circlip
20	0508 1100 18	Bearing
21	3716 0367 00	Cover
22	0663 6146 00	O-ring
23	3716 0012 00	Distributor
24	0663 6139 00	O-ring
25	0661 1536 00	Back-up ring
26	3716 0006 00	Gear wheel
27	0502 2116 00	Ball bearing
28	0663 6152 00	O-ring
29	3716 0368 00	Cover
30	0300 0274 08	Plain washer
31	0663 6140 00	O-ring
32	0661 1537 00	Back-up ring
33	0663 6143 00	O-ring
34	3716 0262 00	Wear washer
35	3716 0022 00	Rubber muff
36	3716 0181 00	Housing
37	0663 6149 00	O-ring
38	3716 0182 00	Cover
39	3716 0268 00	Spring
41	3716 0261 00	Parallel pin
42	0211 1336 00	Cap screw
43	3716 0252 00	Shaft
44	3715 3202 00	Plug
45	3716 0010 00	Wear ring
46	0666 6000 22	Seal
47	0337 7188 00	Parallel key

3716 0248 82

No	Part number	Description
48	3716 0003 00	Spindle
50	0663 6136 00	O-ring
51	3716 0009 00	Wear ring
52	3176 6553 00	Elbow
53	3176 6554 00	Elbow
54	3176 5313 00	Cap
55	3715 0597 00	Cap
56	3716 5577 03	Sign
57	0291 1116 00	Lock nut
58	0211 1569 00	Cap screw
59	0211 1246 00	Cap screw
61	0211 1363 00	Cap screw
62	3716 0025 00	Chuck jaw
62	3716 0132 00	Chuck jaw
62	3716 0346 00	Chuck jaw, Tungsten carbide
62	3716 0344 00	Chuck jaw, Tungsten carbide
63	3715 8807 00	Plug
64	0661 1029 00	Seal washer
65	0661 1014 00	Seal washer
66	3716 2831 00	Gasket